




Dell Optiplex GX620 RAM Replacement

This guide will show you how to remove the memory modules from a Dell Optiplex GX620.

Written By: Kristina



INTRODUCTION

RAM should be replaced if the computer has memory issues. This is sometimes the case when the computer won't boot, or simply runs too slow for comfort.



TOOLS:


- [Anti-Static Wrist Strap](#) (1)
-

Step 1 — Dell Optiplex GX620 Side Panel Disassembly




- With the computer standing upright, firmly pull on the tab at the back of the computer.
- When the side panel pops free, gently pull the panel away from the computer.
- ❗ If you have trouble freeing the side panel from the case, you may need to pull the tab a bit harder.

Step 2 — Press the clips



- Using the tips of your fingers, press out the securing clips on both sides of the memory modules.

Step 3 — Remove the memory



- To remove the memory, pull straight up on the module.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-24 09:23:27 AM.